

# Thermostat Interface Protocol V1.0

## Model:

This protocol takes standard Modbus as a reference, mainly for use for communication between thermostat and computer (PC). This protocol doesn't describe Modbus. For information about Modbus, please refer to the relevant standard documents.

## Settings

### 1. Basic description

No	Parameter	Protocol provision
1	Operating mode	RS-485, master-slave : thermostat is the slave machine
2	Physical interface	A(+),B(-) two-wire system
3	Baud rate	9600 bps(standard)
4	Byte format	9 format (8 data bits +1 stop bit)
5	Modbus	RTU
6	Transmission mode	RTU format (Please refer to standard Modbus)
7	Thermostat address	1—255 ; (0 is broadcast address)
8	Command code	03, 06, and 16 (03—read thermostat, 06—set thermostat, 16-set thermostat for several bytes)
9	CRC check code	CRC—16 (Please refer to standard Modbus)
10	CRC verification mode	CRC—16 (Please refer to standard Modbus)

### 2. Read the thermostat frame format

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Thermostat address (default is 0X01)	03	Set register start address high byte	Set register start address low byte	Set register Value high address	Set register Value low address	CRC high	CRC low

Command	Byte	Description	Register address
03	High Byte	00	40001
	Low Byte	Setting Power On/off: 0—means closed, 1—means open	
	High Byte	00	40002
	Low Byte	Setting Fan Speed: 3 : single fan	
	High Byte	00	40003
	Low Byte	Setting Mode: 0 – Cooling; 1 – Heating; 2 - Ventilation	
	High Byte	00	40004
	Low Byte	Setting Temp. * 10	
	High Byte	00	40005
	Low Byte	Setting Lock: 0 – Unlock; 1 – Lock	
	High Byte	00	40006
	Low Byte	Minute (value 1-59)	
	High Byte	00	40007
	Low Byte	Hour (value 0-23)	
	High Byte	00	40008
	Low Byte	Week (value 1-7), 1-Monday, 2-Tuesday, 3-Wednesday, 4- Thursday, 5- Friday, 6- Saturday, 7- Sunday	
High Byte	00	40009	
Low Byte	Reading Room Temperature: Data is HEX code		
High Byte	00	40010	
Low Byte	Valve On =1 Valve off =0		
High Byte	00	40011	
Low Byte	Fan Status: 3 : single fan		

### 3. Set the thermostat frame format

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Thermostat address (default is 0X01)	03	Set register start address high byte	Set register start address low byte	Set register Value high address	Set register Value low address	CRC high	CRC low

Command	Byte	Description	Register address
06	High Byte	00	40001
	Low Byte	Setting Power On/off: 0—means closed, 1—means open	
	High Byte	00	40002
	Low Byte	Setting Fan Speed: 3- single fan	
	High Byte	00	40003
	Low Byte	Setting Mode: 0 – Cooling; 1 – Heating; 2 - Ventilation	
	High Byte	00	40004
	Low Byte	Setting Temp. * 10	
	High Byte	00	40005
	Low Byte	Setting Lock: 0 – Unlock; 1 – Lock	
	High Byte	00	40006
	Low Byte	Minute (value 1-59)	
	High Byte	00	40007
	Low Byte	Hour (value 0-23)	
	High Byte	00	40008
	Low Byte	Week (value 1-7), 1-Monday, 2-Tuesday, 3-Wednesday, 4- Thursday, 5- Friday, 6- Saturday, 7- Sunday	

### 4. Continuous Multi-byte set the thermostat frame format

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte N-1	Byte N
Thermostat address (default is 0X01)	16(0x10)	Set register start address high byte	Set register start address low byte	Set register Number N* 2	Set register Value high address	Set register Value low address	N set byte value high address	N set byte value low address

Byte N+1	Byte N+2
CRC high	CRC low

Command	Byte	Description	Register address
16 (0x10)	High Byte	00	40001
	Low Byte	Setting Power On/off: 0—means closed, 1—means open	
	High Byte	00	40002
	Low Byte	Setting Fan Speed: 3- single fan	
	High Byte	00	40003
	Low Byte	Setting Mode: 0 – Cooling; 1 – Heating; 2 - Ventilation	
	High Byte	00	40004
	Low Byte	Setting Temp. * 10	
	High Byte	00	40005
	Low Byte	Setting Lock: 0 – Unlock; 1 – Lock	
	High Byte	00	40006
	Low Byte	Minute (value 1-59)	
	High Byte	00	40007
	Low Byte	Hour (value 0-23)	
	High Byte	00	40008
	Low Byte	Week (value 1-7), 1-Monday, 2-Tuesday, 3-Wednesday, 4- Thursday, 5- Friday, 6- Saturday, 7- Sunday	

## Remark

### 1. Format

When the thermostat sends collected temperature data to the PC computer, the value of collected temperature should be multiplied by 10.

For example: **When the collected temperature is 25.5°C**, the value sent from the thermostat to the PC computer will be 255.

Similarly, when the PC computer sends set temperature data to the thermostat, the value of the set temperature should be multiplied by 10.

For example: **When the set temperature is 25.5°C**, the value sent from the PC computer to the thermostat should be 255.

### 2. How to change the thermostat's IP address?

During power off, press **M** and at the same time for 5 seconds to access system functions.

Press **M** till you reach item A.

Then press **▲** and **▼** to change the relative value. The default is 0x01.

Turn on your thermostat to save the IP setting.